

Blanket Clamping Bars

53-A

GTO46  **#42.006.002F**
5 Bolts

53-B

GTO52  **#69.006.002F**
6 Bolts

53-C

MO Offset  **#43.006.002F**
7 Bolts



Worm Gear Blanking Bar
72 / 102 / S-Offset
#66.006.031

53-D

72  **72 Speedmaster**
68.006.002F
8 Bolts




Worm Gear Blanking Bar
72 / 102 - S-Offset
#66.006.029

53-E

102  **#09.006.035F** 10 Bolts

53-H

SM52  **No Photo Available**
Demers Parts Hotline
1-800-956-3612
727-372-1200 **#G2.006.003F**

53-I

SM74  **No Photo Available**
Demers Parts Hotline
1-800-956-3612
727-372-1200 **#M2.006.002**

S Offset

SORK/Z #58.006.002F
SORM/Z #68.006.002F
SOR/Z #66.006.002F
SORD/Z #76.006.002F
SORS/Z #09.006.035F

53-J 

53-L

SM102 Late  **#09.006.035F**
10 Bolt

53-M

CD  **XXXXXXXXXX**
10 Bolt