

Group 38-A Stream Feeder Table

MO-Offset




38-A
Drive Side
#53.849.020F #53.072.090 F
Hook Left




38-B
Operator Side
#53.849.022F #53.072.092 F
Hook Right



38-C
Medium Spring Complete
53.072.094 F



38-D
Operator Side - Hard (card)
Call



38-E
Drive Side - Hard (card)
Call



38-F
Operator Side - Soft (paper)
Call



38-G
Drive Side - Soft (paper)
Call

GTO46 / GTO 52



38-H
Sheet Smoother - Card
#42.022.038



38-I
Sheet Smoother - Paper
#42.022.038



38-J
Guide Spring
#69.022.024 F w/42.002.038 Plate Spring



38-K
Brush w/Hold Down
#04.022.069 F

Feed Table



38-L
Holder Complete
#01.022.016



38-M
Side Piece
#01.022.019 F



38-N
Weight / Holder
#01.022.019 F
#03.017.030 F



38-O
Guide Piece w/Rod
#69.017.077 F

Group 39-A Headstops

102 / SOR / SORD / SORS/Z - Offset



39-Q
Front Lay Finger
#66.072.101



39-R
Tightening Screw
#00.540.0940



39-S
Front Guide
#66.072.102



39-T
Front Guide (cut-out)



39-OO
Front Guide Cutout



39-U
Front Guide Complete
Sold as Assembly See 39 - Q,R,S
#MV.021.586



39-PP
Operator Front Lay "Special" Ass'y
#41.072.157



39-QQ
Operator Front Lay "Special" Ass'y
#41.072.154



39-V
Front Lay Tension Springs
#66.072.108 Larger (4X)



39-W
Hex Head Adjusting
Screw (special)
#66.072.103



39-X
Front Lay Spring
Smaller Type
Call

72 Speed - SORK/Z - SORM/Z



39-Y
Front Guide
#58.022.311 (4X)



39-Z
Sheet Stop
#58.022.312

MO-Offset



39-AA
Front Lay
#43.022.111 (6X)




39-BB
Special Order
1-800-956-3612
Single Sheet Feeder Only Sheet
Stop Middle/Outside
#43.022.128
#43.022.112



39-CC
Stream Feeder Only
Sheet Stop - Outside
#53.022.312



39-DD
Feeder Board 102
#41.072.075



39-EE
Feeder Board SORM
#68.072.075